
1) Check if the brake pads are placed well.



2) Insert the wheel into the front fork and make sure it is straight.



3) Tighten the fastener to the desired tension (not too tight, not too loose) and tighten the safety clamp.






4) Turn the wheel to see if the disc is sitting nicely between the pads. If you do not hear the brake rubbing against the pads, you are safe to drive!

5) If you notice that the brake disc does rub against the brake pads, you need to adjust the

brake (see description below).



□ Unscrew the brake caliper. Take the supplied Allen key and loosen the 2 bolts.





⇒ Squeeze the brake. Keep it depressed until the adjustment is complete.



- ⇒ Tighten the caliper. Now tighten the caliper bolts, hand-tight at first. Then tighten the upper and lower bolts. Meanwhile, keep the handbrake firmly pressed.
- 6) Done!

Need technical assistance? Contact: info@helvei.com or service@houseofmusic.be



